



MGM Brakes

A Division of Indian Head Industries, Inc.

TECHNICAL BULLETIN

SUBJECT: INSTALLATION AND LOCATION INSTRUCTIONS FOR LONG-STROKE TAG ON SINGLE / PIGGYBACK UNITS

IMPORTANT

When replacing with an **MGM TR³ 3 inch stroke “Piggyback Plus” Kit**, be sure to install the enclosed Standardized Trapezoidal Shaped I.D. Tag to one of the service side clamp band bolts and securely fasten it in place with the enclosed pal-nut as shown.

NOTE: Failure to follow this procedure may result in the installation of the wrong diaphragm during some future repair operation.

