

TECHNICAL BULLETIN

SUBJECT: WEATHERSEAL PLUG INSTALLATION INSTRUCTIONS

In order for the brake to function properly and to maintain the warranty coverage, the Weatherseal Plug[™] must be firmly snapped into place in the release tool access hole.

Follow these instructions for easy installation.

- 1. Remove the threaded release tool from the spring chamber. (See Figure 1)
- 2. Align the Weatherseal Plug[™] over the hole in the spring chamber. (See Figure 2)
- 3. Use the round end of the release tool, or equivalent, to press the center of the Weatherseal Plug™ unti it securely "snaps" into place. (See Figure 3)

